

SALTER®

SINCE 1760

Mini Chopper

Instruction Manual

Before First Use

Hand-wash, rinse and dry thoroughly.

Using the Mini Chopper

Remove the lid from the bowl.

Place the chosen fruit or vegetables into the bowl and replace the lid, ensuring that it is secured into position. For the best results, do not overfill the bowl to more than $\frac{1}{4}$ of its capacity.

With one hand firmly holding down the Mini Chopper, gently pull the easy-grip handle and pull cord out to its full length and then slowly release it back in towards the bowl. Repeat until the fruit or vegetables are chopped as required.

Cleaning the Mini Chopper

The Mini Chopper is not dishwasher suitable. Clean the Mini Chopper in warm, soapy water with a mild detergent and a soft cloth; do not use harsh or abrasive cleaners or scourers; rinse and dry thoroughly.

Using extreme caution, clean the stainless steel blade attachment with a brush and dry carefully.

Warning: Handle the stainless steel blade attachment with care, as the blades are extremely sharp.

Storage

Do not store wet; store in a dry, clean place.

Store the stainless steel blade attachment carefully and safely. To prevent injury or damage, it is recommended to always store the stainless steel blade attachment in the bowl.

Caution

The Mini Chopper is only suitable for use with small fruit and vegetables, such as garlic, chilli and spring onion. Larger fruit and vegetables such as apple and carrot must be cut into small chunks before being used with the Mini Chopper.

Exercise caution when attaching, removing, cleaning or storing the stainless steel blade attachment.

Please retain this information for future reference.

If this product proves unsatisfactory or if you have any further queries, please contact your retailer.



Distributed by:

UP Global Sourcing UK Ltd.,
UK. Manchester OL9 0DD.
Germany. 51149 Köln.

Made In China.