

# SALTER®

SINCE 1760

## Dual Electronic Mill

### Instruction Manual

Please retain instructions for future reference.

### Safety Instructions

When using electrical products, basic safety precautions should always be followed.

Children aged from 8 years and people with reduced capabilities can use this product, only if they have been given supervision or instruction concerning safe use of the and understand the hazards involved.

This product is not a toy.

This product contains no user serviceable parts.

If the product and any of its accessories are malfunctioning or damaged, recycle the product.

Keep the product away from heat sources, direct sunlight, humidity, water and any other liquid.

Do not operate the product with wet hands.

Do not operate the product if it has been exposed to water, moisture or any other liquid, to prevent against electric shock, explosion and/or injury to yourself and damage to the product.

Do not use the product for anything other than its intended use.

Do not use any accessories other than those supplied.

### Care and Maintenance

Wipe the mill with a soft, damp cloth and allow to dry thoroughly.

Do not immerse the mill in water or any other liquid. Never use harsh or abrasive cleaning detergents or scourers to clean the mill, as this could cause damage.

**Note:** Not suitable for dishwasher use.

### Installing the Batteries

This product requires 6 x AAA batteries (not included).

**STEP 1:** To install or replace the batteries, remove the upper cap by turning it in an anticlockwise direction and lifting up and away from the mill.

**STEP 2:** Carefully remove the exhausted batteries (if applicable). Insert 6 x AAA batteries into the battery compartment, observing the correct polarity.

**STEP 3:** Replace the upper cap and twist it in a clockwise direction until secure.

### Filling the Dual Electronic Mill

**STEP 1:** To fill the mill, remove the upper cap by turning it in an anticlockwise direction and lifting up and away from the mill.

**STEP 2:** Carefully remove the battery compartment.

**STEP 3:** Fill the chambers marked 'S' and 'P' with your choice of dry coarse sea salt (not flakes or rock salt) and standard sized dried peppercorns.

**STEP 4:** Replace the battery compartment.

**STEP 5:** Replace the upper cap and twist it in a clockwise direction until secure.

### Using the Dual Electronic Mill

Push 'P' to dispense pepper.

Push 'S' to dispense salt.

## Adjusting for Fine or Coarse Grinding

**STEP 1:** Turn the mill upside down.

**STEP 2:** To adjust the coarseness of the grind, loosen or tighten the grind adjust knob. Turn it clockwise for a finer grind or anticlockwise for a coarser grind.

**Caution:** Take care not to overtighten the grind adjust knob, as this could cause damage to the ceramic mill stones.


Residue may build up around the dispensing mechanism, which can prevent the finest grind setting from working. If this happens, turn the mill upside down and push 'S' or 'P' to begin grinding and release the trapped residue. The finest grind setting can now be used.

## Specifications

Product code: BW11378BRMFOB

Batteries required: 6 x AAA (not included).

## Disposal of Waste Batteries and Electrical & Electronic Equipment

 This symbol on the product, its batteries or its packaging means that this product and any batteries it contains must not be disposed of with household waste. Instead, it is the user's responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. For more information about where to drop batteries, electrical and electronic waste off, please contact the local city/municipality office, household waste disposal service, or the retailer.

Imported & Distributed by:  
Brand Merchant Pty Ltd Suite 8,  
SA St Andrews Street,  
Brighton Victoria 3186, Australia.

[www.brandmerchant.com.au](http://www.brandmerchant.com.au)

© Salter Trademark. All rights reserved.

CDD81121/MD000000/V1

